Exporting Dahua Video Clips with SmartPSS (network access)

This method is ideal for exporting footage remotely from your computer without needing physical access to the NVR.

What you'll need

- SmartPSS Software: Dahua's free PC client software: https://dahuawiki.com/SmartPSS_Lite
- Network Access: Both your PC and NVR must be on the same local network.

Steps

- 1. Launch SmartPSS. Open the software and go to the Playback tab.
- 2. **Add your NVR.** Ensure your NVR is added to the SmartPSS device list. On the Playback screen, find your NVR in the device tree on the left.
- 3. **Search for footage.** Set your desired parameters, including:
 - Channel(s): Select the camera(s).
 - Date and Time: Specify the date and time range.
 - Type: Select the recording type (e.g., General, Motion).
 - Stream Type: Select Main for the highest quality footage.
- 4. **Initiate the export.** Click the Search button. A timeline will appear, and you can play back the footage.
- 5. **Use the clipping tool.** To export specific portions, click the "Time Clip" or scissors icon to mark a start and end point on the timeline. Click the scissors icon again to finalize your selection.
- 6. **Set export options.** An export window will appear. Choose the following settings:
 - o **Path:** Browse to the folder on your PC where you want to save the video.
 - Export Format: Select MP4 for playback on most media players.
- 7. **Start the download.** Click or to begin the export. You can monitor the progress in the Export Progress window